

Building something TIP-SOP-130 - Tipping at Thornleigh Concrete great

Sop Title:	Tipping at Thornleigh Concrete Plant	Sop No:	TIP-SOP-130
Sop Location:	23 Sefton Road, Thornleigh NSW 2120	Associated Documents:	TIP-SWMS-005 Tipping - General TIP-SWMS-007 Unloading Live Bottom Semi-Trailer TIP-SOP-005 Tipping - General TIP-SOP-007 Unloading Live Bottom Semi-Trailer
Date of Issue:	11/04/2025	Next Review Date:	11/04/2027
Issue Version:	1.0	Authorised By:	Jeremy Wee
Frequency:	Every load		
Purpose:	Safe delivery of aggregate materials	s as per plant demand	
Responsibility:	Tipper driver	Requirements:	Correct PPE - High Visibility clothing - Long Pants & Sleeves - Hard Hat - Safety Glasses - Gloves - Safety boots
Compliance:		PPE Requirements:	
- WHS Act 2011 - WHS Regulation 2017 - HVNL Act 42a 2013			

Step	Activity	Safety/ Quality/ Performance Notes	Photo
1.	Driver approaches concrete plant	 Contact batch office on UHF 9 and inform of your fleet number and product on-board Receive confirmation and directions from batch relating to other movements onsite If no answer from the plant do not drive in the plant Notify batch office if you are not site inducted Site operational hours Monday to Friday 7:00am – 5:00pm. Saturday 8:00am – 1:00pm 	
2.	Driver to enter concrete plant	- Enter from Sefton Road entrance gate No.1 - Shared entrance with Tankers - Be aware of pedestrians	



Building something TIP-SOP-130 - Tipping at Thornleigh Concrete great

Step	Activity	Safety/ Quality/ Performance Notes	Photo
3.	Position dog trailer or live bottom semi- trailer for unloading	 Position the last axle on the edge of concrete or as directed by the site personnel Ensure to get clear instructions from site personnel when to start unloading 	
4.	Unloading Dog Trailer/ Live bottom semi- trailer	 Follow TIP-SOP-005 Tipping – General or TIP-SOP-007 Unloading Live Bottom Semi-Trailer Ensure the batcher is guiding you when tipping due to limited bin capacity Raise body in small increments and monitor product flow Batcher may ask you to stop tipping at any point to allow the bin to empty If communication is lost, stop unloading immediately Should the material overflow at any point, contact the batcher At no point is the driver to shovel product Once unloaded move forward 300- 500mm Clean the tailgate locks and sweep the ground bin as per normal procedure 	GONDAT TO STATE OF THE PARTY OF
5.	Positioning and unloading the truck	 Follow TIP-SOP-005 Tipping - General Refer to step 4 to unload the truck Clean the tailgate locks, drawbar and sweep the ground bin Should the material overflow at any point, contact the batcher At no point is the driver to shovel product Clean the tailgate locks and sweep the ground bin as per normal procedure 	
6.	Exit the site	- Positive communication - Follow site TMP - Exit site via gate 2	



Building something TIP-SOP-130 - Tipping at Thornleigh Concrete Plant

Prepared By / Review Team			
Name	Position	Signature	Date
Marko Kasap	Driver Trainer / Safety Committee Member	ALS.	11/04/2025
Victoria Piserchia	Supervisor	D	11/04/2025

Authorisation		
I have checked this Standard Operating Procedure (SOP) and confirm that it is authorised for use.		
Person supervising the work	Signature	Date
Jeremy Wee	form.	11/04/2025