Traffic & Pedestrian Management Plan Induction



Mugga Concrete Plant

Emergency Site Map









Protected Walkway



Pedestrian Exclusion Zone Only authorised pedestrians are permitted to conduct work in operational areas

Emergency Stations

Emergency Assembly Area Located in the Visitor & Employee car park



Main Electrical Located in Office



First Aid Located in Driver's Room



Emergency Eye Wash Located in Batching area & Truck Wash location



Fire Extinguishers

Are located in each of the following areas: Office (3), Driver's Room (1), Material bins (1)



Fire Blanket

Located in Driver's Room

Traffic & Pedestrian Management Plan Visitor Site Map





Pedestrians Protected Walkway Designated Walkway Pedestrians **MUST** give way to vehicles and plant Pedestrian Exclusion Zone Only authorised pedestrians

in operational areas

are permitted to conduct work

Vehicles and Plant

Follow the direction of the vehicle route. Drivers MUST not exit their vehicle unless they can access a designated walkway or to complete designated work.



Site Speed Limit

The site speed limit is restricted to 20kph



Visitor Parking

- Visitors park in the Visitor & Employee Car Park.
- Reverse parking only.
- All visitors must report to the office immediately upon arrival. Follow the pathway directional arrow to and from the office, as indicated on the map.



- Operates in all areas.
- Has right of way in vehicle operating areas. Always establish positive communication (verbal and/or visual contact) with operator before approaching within 20 metres

Traffic & Pedestrian Management Plan Courier Delivery Site Map (Light Vehicle)





Pedestrians



Designated Walkway
Pedestrians MUST give way
to vehicles and plant



Pedestrian Exclusion Zone Only authorised pedestrians are permitted to conduct work in operational areas

Vehicles and Plant



Vehicle RouteFollow the direction of the vehicle route. Drivers MUST not exit their vehicle unless they can access a designated walkway or to complete designated work.



Site Speed Limit

The site speed limit is restricted to 20kph



Courier Parking

- Couriers park in the Visitor & Employee Car Park.
- Reverse parking only.
- All Couriers must report to the office immediately upon arrival. Follow the pathway directional
 arrow to and from the office, as indicated on the map.



- Operates in all areas.
- Has right of way in vehicle operating areas. Always establish positive communication (verbal and/or visual contact) with operator before approaching within 20 metres


Traffic & Pedestrian Management Plan Heavy Vehicle Delivery Site Map (Requiring Forklift)







in operational areas



Tipper Site Map

(Driver must contact office on UHF channel 25 prior to entering site)









Designated WalkwayPedestrians **MUST** give way to vehicles and plant

Pedestrian Exclusion Zone
Only authorised pedestrians

Only authorised pedestrians are permitted to conduct work in operational areas

Vehicles and Plant

Vel

Vehicle Route

Follow the direction of the vehicle route. Drivers MUST not exit their vehicle unless they can access a designated walkway or to complete designated work.



Reverse Entry



Site Speed Limit

The site speed limit is restricted to 20kph



Tipper Discharge Location

Reverse entry



Tipper Parking area

When access to the office is required, park in the Tipper Parking area. Follow the pathway directional arrows to and from the office, as indicated on the map.



- Operates in all areas.
- Has right of way in vehicle operating areas. Always establish positive communication (verbal and/or visual contact) with operator before approaching within 20 metres


Powder Tanker Site Map












Admix Bulk Tanker Site Map



(Driver must contact office on UHF channel 25 prior to entering site)







Traffic & Pedestrian Management Plan Agitator Site Map







are permitted to conduct work

in operational areas

Vehicles and Plant



Vehicle Route

Follow the direction of the vehicle route. Drivers MUST not exit their vehicle unless they can access a designated walkway or to complete designated work.



Reverse entry

Reverse entry into the following areas:

- Agi Loading Point
- Washout Bays
- Additive Loading Point
- Returned Concrete Unloading Point



Site Speed Limit

The site speed limit is restricted to 20kph



Agitator Loading Point

Reverse entry



Waiting area

When the Agitator Loading point is unavailable, park in the waiting area to be next in line. Alternatively, if the waiting area is unavailable, park in the overflow waiting area.



Agitator Parking Bays

- Parking is reverse entry only.
- Do not park in first parking space, as indicated on map.



- Operates in all areas.
- Has right of way in vehicle operating areas. Always establish positive communication (verbal and/or visual contact) with operator before approaching within 20 metres


Loading Washout Waste Site Map











Loading Hard Waste Site Map












Protected Walkway





Pedestrian Exclusion Zone

Only authorised pedestrians are permitted to conduct work in operational areas

Vehicles and Plant



Vehicle Route

Follow the direction of the vehicle route. Drivers MUST not exit their vehicle unless they can access a designated walkway or to complete designated work.



Site Speed Limit

The site speed limit is restricted to 20kph



Hard Waste Loading Location



- Operates in all areas.
- Has right of way in vehicle operating areas. Always establish positive communication (verbal and/or visual contact) with operator before approaching within 20 metres

Traffic & Pedestrian Management Plan **Contractor Site Map**





Pedestrians



Protected Walkway



Designated Walkway Pedestrians MUST give way to vehicles and plant



Pedestrian Exclusion Zone Only authorised pedestrians

are permitted to conduct work in operational areas

Vehicles and Plant



Follow the direction of the vehicle route. Drivers MUST not exit their vehicle unless they can access a designated walkway or to complete designated work.



Site Speed Limit

The site speed limit is restricted to 20kph



Contractor Parking

- Contractors park in the Visitor & Employee Car Park.
- Reverse parking only.
- Upon arrival, Contractors must report to the office for induction and further instructions. Follow the pathway directional arrow to and from office, as indicated on the map.



- Operates in all areas.
- Has right of way in vehicle operating areas. Always establish positive communication (verbal and/or visual contact) with operator before approaching within 20 metres