

Sop Title:	Uncouple/ Couple Semi-Trailer	Sop No:	TIP-SOP-009	
Sop Location:	Multiple	Associated SWMS: TIP-SWMS-009		
Date of Issue:	1/05/2025	Next Review Date:	1/05/2027	
Issue Version:	1.0	Authorised By:	Jeremy Wee	
Frequency:	When required			
Purpose:	Uncouple/ Couple Semi-Trailer	ple/ Couple Semi-Trailer		
Responsibility:	Tipper driver	Requirements:	Prime mover Semi-Trailer UHF Radio Correct site PPE - High Visibility clothing - Long Pants & Sleeves - Hard Hat - Safety Glasses - Gloves - Wheel chocks - where required	
Compliance:		PPE Requirements:		
- WHS Act 2011 - WHS Regulation 2017				

Step	Activity	Safety/ Quality/ Performance Notes	Photo
1.	Arrive at site	 Positive communication Be aware of your surroundings Ensure to uncouple the vehicle combination on firm and level ground 	IORA COMPANY OF THE PARTY OF TH



Step	Activity	Safety/ Quality/ Performance Notes	Photo
2.	Uncouple the vehicle combination	 Park the vehicle ensuring firm and level ground and that the prime mover is in line with the semi-trailer Exit the vehicle maintaining 3 PoC Climb to the back of the cab Turn off the brake air taps On the trailer side disconnect air lines, EBS plug, electrical plugs, reverse camera and hydraulic hoses Secure the hydraulic hoses, air lines and electrical plugs for transit Enter the truck, perform a tug test If unsuccessful refer to maintenance reporting system If successful, continue with uncoupling procedure Apply maxi park brakes Exit the cab Lower the landing legs Release turntable safety catch Pull the turntable handle out to release the pin Enter the cabin Select forward gear Drive forward 300mm Lower air bags Ensure trailer is being supported by the landing legs Drive forward until clear of trailer Raise air bags to drive level 	TOURISM DESCRIPTION DESCRIPTION DESCRIPTION OF THE PROPERTY OF



Step	Activity	Safety/ Quality/ Performance Notes	Photo
3.	Coupling the vehicle combination	 Lower air bags on the prime mover Reverse slowly in a straight line toward the trailer stopping when the rear axle mud guard go under the front of the semi-trailer Apply maxi park brakes and exit the cab Visually inspect the height of the semi-trailer and straight alignment Inspect that the turntable jaws are open Adjust if required Enter the cab and reverse the prime mover until the turntable is under the trailer, then raise air bags until trailer start to lift Continue reversing until turntable jaws lock around the king pin and audible click is heard Perform a soft tug test Apply maxi park brakes Turn on park lights and hazard lights Exit cab Visual check that jaws are locked around the king pin Visual check that turntable handle and safety catch are in locked position Raise the landing legs Climb to the back of the cab Connect air lines, EBS plug, electrical plugs, reverse camera and hydraulic hoses Turn on brake air taps Walk around the vehicle combination and check all the lights and indicators are working Enter cab and perform a tug test 	
4.	Exit uncoupling	Turn off indicators and lights if day timeBe aware of your surroundings	



Prepared By / Review Team			
Name	Position	Signature	Date
Marko Kasap	Driver Trainer / Safety Committee Member	Wb -	1/05/2025
Victoria Piserchia	Supervisor	D	1/05/2025

Authorisation		
I have checked this Standard Opera	ting Procedure (SOP) and confirm that	it is authorised for use.
Person supervising the work	Signature	Date
Jeremy Wee	Jony	1/05/2025